


KG167 Clinic Room Hatch



Product datasheet



Hatch shown from the corridor side



Anti-ligature Disclaimer

Anti-ligature Disclaimer The anti-ligature design characteristics of this product are not intended to replace or substitute the need for necessary supervision of those who may be at risk, or for other necessary protective measures to be taken in the specific circumstances of usage. Kingsway Group, Inc. does not offer any products for sale as being 'ligature-free' and will not be liable for any claims arising from ligature attachment on its products. It is the customer's responsibility to ensure that products purchased and installed are suitable for the environments they are installed in.

The KG167 Clinic Room Hatch is a secure opening hatch that is installed into doors to provide a secure serving solution. Manufactured to allow items to be passed out of a secure room removing the requirement for the door to be opened for communications or patient serving.

Installation Description

- Cut out the required aperture in the door to suit the unit using the template supplied.
- Fix the inner part of the food hatch and make sure that it is level
- Fix the front fascia and ensure that all fixings are secure before operation.

Operation and Maintenance

Operation

To pass an object through the door, unlock the hatch from the staff side and open the hatch into the open position. Pass the object or communicate through the hatch.

Maintenance

Light lubricant can be used on moving parts and periodic checks should be made to the latch to ensure this is operating smoothly.

Cleaning

The hatch can be cleaned using standard commercial detergents and cleaners but care should be taken to avoid cleaning with abrasive cloths which will scratch the surfaces of the unit.

Guarantee

5 Year Guarantee*

For faulty manufacture, not for damage

Specification

KG167 Anti-Ligature Secure Observation Door Hatch for 1-3/4" Door