

PRODUCT DATASHEET

# KG362 Access Panel 450 x 450mm

Secure access panels to allow ease of operation yet protect against abuse and self harming. These secure steel panels are manufactured to allow ease of access to vital services yet guard against physical abuse and the risk of fire. Fitted with a heavy duty deadbolt lock and operated by a euro cylinder which is protected by a solid stainless steel escutcheon.



### Terms and conditions:

To see our full terms and conditions, please visit:  
[kingswaygroupglobal.com/en-au/terms](https://kingswaygroupglobal.com/en-au/terms)

# Your Partner in Patient Safety

## Installation Description

- Mark out the location of the hatch
- Cut out the opening
- Secure the access panel into the opening using the security fixings provided
- We recommend that all access panels are also sealed around all sides with anti-pick mastic

## Operation and Maintenance

### Operation

To open the access panel, unlock the latch on the face of the access panel, allowing the door to swing freely. To return to the locked position, push the panel back into the recess and lock to secure.

### Maintenance

Care should be taken to ensure that the lock remains functional and free from signs of damage or tampering.

### Cleaning

Use only a damp cloth to clean the access panel. Where necessary a mild detergent can be used.

## Guarantee

### 5 Year Guarantee\*

\*For faulty manufacture and not for damage

### Specification

KG362 Access Panel 450 x 450mm